Accessories Set VR001

Installation Manual

For further information, please consult www.arctic.ac

Compatibility

ATI Radeon HD 6870, 5870, 5830, 4890, 4870, 4850, 4830, 3870, 3850
nVIDIA GeForce GTS 250, 9800GTX+, 9800GTX

Accessories

Heatsinks x 4	Heatsinks x 8
Heatsinks x 4	Heatsinks x 4
Heatsinks x 4	*Thermal adhesive (3g) x 1 

*Be aware that the thermal adhesive comes with a very short shelf life and shall be used within 1 week upon receipt. We recommend storing the thermal adhesive in a cool area to avoid solidification. Refrigerate after opening. Additional heatsinks and thermal adhesive are available for purchase at xtreme.arctic.ac

Tips for applying thermal adhesive

RAM



Voltage regulator



Apply pressure (10 sec)



Cure time

Caution: Please make sure the heatsinks are not touching any circuit components as it may cause a short circuit to your VGA card.

How to squeeze out all the glue?



Installation of RAM and voltage regulator heatsinks

1



2



Installation of main cooler

Please follow the installation instructions provided with the main cooler.

ARCTIC Switzerland
Huobstrasse 4
8808, Pfäffikon, Switzerland
www.arctic.ac

Copyright©
2010 ARCTIC Switzerland. All Rights Reserved.
No part of this manual including the products described in it, may be reproduced, transmitted, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ARCTIC Switzerland. In no event shall ARCTIC its directors or employees be liable for any indirect damages, incidental or consequential damages arising from any defect or error in this manual or product.